

# RC4 Wireless Quick-start-guide

## Lumendim2micro - wireless DMX receiver dimmer

### Buttons & Indicators

As with all other RC4 Series 3 devices, restore defaults is done by holding Func, tapping SetA, and releasing Func. With no DMX data present, SetA and SetB are "bump" buttons that test the dimmers at 75% while pressed. When DMX data is present, they are used to assign a DMX channel and dimmer curve to the respective dimmer.

